

Installation Instructions

Eibach Inc. 264 Mariah Circle Corona, CA 92879
USA Tech Support 800-507-2338 ext. 114



PRO-LIFT-KIT-HD: E30-82-105-06-02

4TH GEN TOYOTA TACOMA HYBRID

Notes

The Pro Truck HD springs must not be used with the OE shocks. Extended travel shocks are required to avoid damage to the suspension.

Designed for use with 1000lbs static load over rear axle

Kit Contents

Description	Part Number	Quantity
REAR SPRING	F31-82-105-06-RA	2

Installation Notes

Read all instructions before beginning installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and Piston rod nuts.
- All Eibach springs should be installed with the Eibach logo right-side-up. All original stock spring isolators and dampers should be retained from the stock springs when installing Eibach springs.
- After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel fender clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- For MacPherson Strut type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the springs. Noise may result if this procedure is not performed correctly.

Additional Eibach Components for your Vehicle

Eibach Kits	Part Number	Description	Front	Rear
PRO-TRUCK SPORT SHOCK REAR	E60-82-105-01-01	EXTENDED LENGTH		+0-1.5"
PRO-TRUCK RESERVOIR SHOCK REAR	E60-82-105-02-01	EXTENDED LENGTH		+0-1.5"

Installation Instructions

Eibach Inc. 264 Mariah Circle Corona, CA 92879
USA Tech Support 800-507-2338 ext. 114



Lift Table for added Weight	
TACOMA HYBRID, Rear 1000LBS WITH WEIGHT OVER REAR AXLE	
Added Weight (Lbs)	Lift (in)
0	+3.0"
100	+2.8"
200	+2.6"
300	+2.4"
400	+2.2"
500	+2.0"
600	+1.8"
700	+1.6"
800	+1.4"
900	+1.2"
1000	+1.0"